

SUPREME[®]

TRIMMER

The World's Trimmer Company[®]



Follow us on Social Media
For Daily Content



FOLLOW US: @SUPREMETRIMMER

SUPREME[®]


TRIMMER

USER MANUAL
WARRANTY CARD



MULTIGROOMER[®] 3.0

ALL-IN-ONE TRIMMER[®]



User Manual Warranty Card

PG 1: Accessories & Functions

PG 2: Guide Combs & Maintenance

PG 3: QR Codes

PG 4: Warranty & Customer Service

TECHNICAL PARAMETER

Input: DC 5V Worldwide Voltage: 100-240V


Rated Voltage: 3.7V Power: 5W

Charging Time: 120 mins Run Time: 120 mins


ALL-IN-ONE TRIMMER[®]




**T-SHAPED BODY
TRIMMER**



NOSE/EAR TRIMMER




BEARD TRIMMER



HAIR TRIMMER

ACCESSORIES / FUNCTIONS



The Multigroomer 3.0 is our first home-use tool, designed for all-in-one grooming with three unique head attachments for your head, face, ears, and nose. Perfect for travel and everyday use, this affordable beard trimmer offers universal charging for global convenience. This 14-piece set includes everything you need for versatile grooming, providing a complete package for your grooming routine.

Ensure the teeth on the blades are not damaged or bent.

Contact customer service if you received them damaged.

GUIDE COMBS & MAINTENANCE



(Fig.1)



(Fig.2)



(Fig.3)

4 guide combs (3/6/9/12mm) and an adjustable guard are included in your kit to be used on your T-Blade.

1 beard guard (2-6mm) is included to be used on your U-Blade.

Insert the blade teeth into the guard and push down end bill.

Using the Nose & Ear Trimmer

- Only use the trimmer at the entrance of the ear or nose.
- Insert the trimmer into the nose or ear and gently move the trimmer in circular motions.
- Never turn the trimmer off while trimming nose or ear hair.

SMG3030 is IPX6 Waterproof, which can be used, cleaned and rinsed under water. To clean the guards, they can be rinsed under running warm water. To clean the blades, you can dip them in cleaning solution or soap water and turn on the machine until all hair has been removed. Dry thoroughly before storing.

Activate / Deactivate travel lock for safe storage – Hold On/Off button for 5 seconds. Will reflect on LCD Screen.

HEAD IN THE RIGHT DIRECTION



Welcome to Our
Amazon Storefront



Barber Approved, Barber Suggested
Clippers & Trimmers



Regain your Confidence with
Hair Fibers



Welcome to Our
Website



Buzz Worthy
Electric Foil Shavers



Check out Whats New
Latest Arrivals

WARRANTY INFORMATION

24 MONTH LIMITED WARRANTY AGAINST DEFECTS OR LACK OF CRAFTSMANSHIP.

Our product carries warranty against defective material of workmanship for 2 full years from the date of purchase. Any product determined to be defective in material or workmanship during the warranty period will be repaired or replaced without the cost of parts or labor to consumer.

CUSTOMER SERVICE

Please reach out to our Customer Service team for any Questions or Concerns regarding your Multigroomer. We are here to assist on all matters and take great pride in taking care of our customers.



Scan OR code to Submit a "Contact Me" Form

Call, Text OR Email: M-F 8 AM-3 PM PST
Email: support@supremetrimmer.com
Phone: +1 (818) 626-8065 (USA)
Website: WWW.SUPREMETRIMMER.COM