

SUPREME[®]

TRIMMER



Model:STF101/BLACK
Electric Shaver

Please read the instructions manual before operating.

Instruction Manual

SUPREME[®]

TRIMMER

against your hair while maintaining contact with the foil.

8. In order to achieve the closest shave and avoid unnecessary wear on the foils, be sure that both foils contact the skin simultaneously all the time. Holding the shaver at an angle where only one foil contacts the skin will cause distortion of the foil and may result in skin irritation.
9. To facilitate cutting and avoid foil wear, use minimal pressure to apply to the shaver to your skin.
10. To maximize shaving comfort, be sure to clean the shaver thoroughly after each use.

USER MAINTENANCE




If shaver will be unused for a long period of time, please store it in a safe, cool, dry place. Don't wrap cord tightly around shaver. Do not hang the shaver by the power cord.

DRY CLEANING WITH BRUSH


1. Remove the foil assembly by pressing the button located on the right side of the unit. Grasp the foil assembly on both sides and gently lift it off the shaver.
2. Gently tap the base of the foil assembly on a flat surface so that the hairs inside can fall out.
3. Lightly brush the hairs out from the cutters. You can remove them from the shaver if necessary. Blow out any remaining loose hairs.
4. Reassemble the cutters and foil assembly after drying them thoroughly.



This product contains recyclable materials. Do not dispose this product as unsorted municipal waste. Please contact your local municipality for the nearest collection point.



KIT INCLUDES:



- ① Electric shaver
- ② Cleaning brush
- ③ Storage bag
- ④ USB charging cord
- ⑤ Charging adapter
- ⑥ Instruction manual
- ⑦ Warranty card

SPARE PARTS

Please reach out to us if you can purchase Foil and cutter separately (model SB11)

Product troubleshooting

Common issues

Issues	Possible reasons	Solutions
Bad shaving performance	Blade mesh is damaged or abrasion Dirty and stuck blade mesh Low battery	Replace the blade mesh Clean the blade mesh throughly Connect and charge the shaver
Cannot be switch on	Flat battery Power button failed	Connect and charge the shaver File a warranty claim with our customer service
No flashing light when charging	Charging light or electric circuit error	File a warranty claim with our customer service
Skin allergy after shaving	Your skin may take times to adapt to the electric shaver	Around 2-3 weeks adaptation period.
Charging failed	Shaver is broken down Charging temperature is too low or too high	File a warranty claim with our customer service Charge the shaver under an environment of 41 ℉ to 95 ℉

Please Reach out to our Customer Service team for any Questions or Concerns regarding your STF101 Solo Foil



Email: support@supremetrimmer.com

Phone: 1-818-626-8065 (USA)

Website: www.supremetrimmer.com



FOLLOW US: @SUPREMETRIMMER